



# Aqara Vibration Sensor T1

## – FAQ



### What can the Vibration Sensor T1 do?

The Vibration Sensor T1 detects vibration, tilt, and drop, helping monitor movement and potential disturbances.

### Can the Vibration Sensor T1 be used independently? Will it sound an alarm when vibrations are detected?

No. The Vibration Sensor T1 needs an Aqara Hub to function. When it detects vibrations, it triggers the hub to sound an alarm and sends a notification to your phone. It can also interact with other smart devices through automations.

### How do I change the battery of the Vibration Sensor T1?

1. Use a coin to turn the battery cover counterclockwise until it loosens.
2. Remove the old battery and insert a new CR2032 battery, ensuring the positive side faces up.
3. Align the battery cover and turn it clockwise with a coin until it clicks, securing the cover in place.

### How can I check if the Vibration Sensor T1 will work in the desired location?

After pairing the sensor with the hub, press the reset button at the intended location before installation. If the hub says *"normal link confirmed,"* the location is suitable. If there's no voice prompt, move the sensor closer to the hub and try again.